TECHNICAL MANUAL

ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS

FOR

METEOROLOGICAL DATA PROCESSING GROUPS

OL-192/GMD-1 (NSN 6660-01-065-4467)

AND

OL-192A/GMD-1 (NSN 6660-01-065-4466)

HEADQUARTERS, DEPARTMENT OF THE ARMY
14 May 1981

TECHNICAL MANUAL
No. 11-6660-263-20P

HEADQUARTERS
DEPARTMENT OF THE ARMY,
WASHINGTON, DC, *14 May 1981*

ORGANIZATIONAL MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LISTS

FOR

METEOROLOGICAL DATA PROCESSING GROUPS OL-192/GMD-1 (NSN 6660-01-065-4467) AND OL-192A/GMD-1 (NSN 6660-01-065-4466)

Current as of 30 November 1980

REPORTING ERRORS AND RECOMMENDING IMPROVEMENTS

You can help improve this manual. If you find any mistakes or if you know of a way to improve the procedures, please let us know. Mail your letter, DA Form 2028 (Recommended Changes to Publications and Blank Forms), or DA Form 2028-2, located in the back of this manual direct to: Commander, US Army Communications and Electronics Materiel Readiness Command, ATTN: DRSEL-ME-MQ, Fort Monmouth, NJ 07703.

In either case a reply will be furnished direct to you.

Table of Contents

			Page	Illus Figure
SECTION	I.	Introduction	1	
	II.	Repair parts list	5	
Group	00	Meteorological Data Processing Groups OL-192/GMD-1 and OL-192A/GMD-1	5	1
	01	Calculator, Programmable CP-1387/U	9	2
		0101 Memory assembly (No parts authorized)		
		010101 16K byte read write memory circuit card (No parts authorized)		
		010102 8K byte read write memory circuit card (No parts authorized)		
		0102 Circuit card assembly processor board (No parts authorized)		
		0103 Circuit card assembly tape transport logic board (No parts authorized)		
		0104 Base assembly (No parts authorized)		
		010401 Circuit card assembly ROM interface (No parts authorized)		
		010402 Circuit card assembly power supply board (No parts authorized)		
		010403 Circuit card assembly I/O interface (No parts authorized)		
		010404 Housing assembly, transformer	11	3
		0105 Bezel assembly, calculator	13	4
		010501 Transport, magnetic tape (No parts authorized)		
		010502 Printer, thermal (No parts authorized)		
		010503 Display board (No parts authorized)		
		010504 Keyboard, calculator (No parts authorized)		
		0106 Keyboard, display printer board assembly (No parts authorized)		
		0107 Mainframe ROM (No parts authorized)		
		0108 ROM string-advanced program (No parts authorized)		
		0109 ROM general I/O, extended I/O (No parts authorized)		
	02	Perforator/Reader RP-263/GMD-1	17	5
		0201 Perforator assembly (No parts authorized)		
		0202 Front panel assembly, switch plate assembly	19	6

			Page	Illus Figure
	0203	Reader panel assembly (No parts authorized)		
	0204	Chassis assembly (No parts authorized)		
	020401	Supply deck (No parts authorized)		
	0205	Perforator logic card assembly (No parts authorized)		
	0206	Perforator driver card assembly (No parts authorized)		
	0207	Reader card assembly (No parts authorized)		
	0208	Power supply assembly	21	7
		Power supply assembly, transformer assembly	23	8
	020801	Printed circuit card assembly, power supply	27	9
03		Cable Assembly, Special Purpose CX-13096/U (No parts authorized)		
	0301	Control board assembly (A1) (No parts authorized)		
	0302	Data board assembly (A3) (No parts authorized)		
04		Meteorological Data Processing Group CY-7761/GMD-1 (No parts authorized)		
05		Case, Calculator, Programmable CY-7762/GMD-1 (No parts authorized)		
06		Case, Reader-Perforator CY-7763/GMD-1 (No parts authorized)		
SECTION III.		Special tools list (Not applicable)		
IV.		National stock number and part number index	28	

SECTION I
INTRODUCTION

1. Scope

This manual lists spares and repair parts; special tools; special test, measurement, and diagnostic equipment (TMDE), and other special support equipment required for performance of organizational maintenance of the OL-192/GMD-1 and OL-192A/GMD-1. It authorizes the requisitioning and issue of spares and repair parts as indicated by the source and maintenance codes.

2. General

This Repair Parts and Special Tools List is divided into the following sections:

a. Section II. Repair Parts List. A list of spares and repair parts authorized for use in the performance of maintenance. The list also includes parts which must be removed for replacement of the authorized parts. Parts lists are composed of functional groups in numeric sequence, with the parts in each group listed in figure and item number sequence.

b. Section III. Special Tools List. Not applicable.

c. Section IV. National Stock Number and Part Number Index. A list, in National item identification number (NIIN) sequence, of all National stock numbers (NSN) appearing in the listings, followed by a list, in alphameric sequence, of all part numbers appearing in the listings. National stock numbers and part numbers are cross-referenced to each illustration figure and item number appearance.

3. Explanation of Columns

a. Illustration. This column is divided as follows:

(1) *Figure number.* Indicates the figure number of the illustration on which the item is shown.

(2) *Item number.* The number used to identify item called out in the illustration.

b. Source, Maintenance, and Recoverability (SMR) Codes.

(1) *Source code.* Source codes indicate the manner of acquiring support items for maintenance, repair, or overhaul of end items. Source codes are entered in the first and second positions of the Uniform SMR Code format as follows;

Code	*Definition*
PA	Item procured and stocked for anticipated or known usage.
PD	Support item, excluding support equipment, procured for initial issue or outfitting and stocked only for subsequent or additional initial issues or outfittings. Not subject to automatic replenishment.
XD	A support item that is not stocked. When required, item will be procured through normal supply channels.

NOTE

Cannibalization or salvage may be used as a source of supply for any items source coded above except those coded XA and aircraft support items as restricted by AR 700-42.

(2) *Maintenance code.* Maintenance codes are assigned to indicate the levels of maintenance authorized to USE and REPAIR support items. The maintenance codes are entered in the third and fourth positions of the Uniform SMR Code format as follows:

(a) The maintenance code entered in the third position will indicate the lowest maintenance level authorized to remove, replace, and use the support item. The maintenance code entered in the third position will indicate one of the following levels of maintenance:

Code	*Application/Explanation*
O	Support item is removed, replaced, used at the organizational level.

(b) The maintenance code entered in the fourth position indicates whether the item is to be repaired and identifies the lowest maintenance level with the capability to perform complete repair (i.e., all authorized maintenance functions). This position will contain one of the following maintenance codes:

Code	*Application/Explanation*
D	The lowest maintenance level capable of complete repair of the support item is the depot level.
Z	Nonreparable. No repair is authorized.

(3) *Recoverability code.* Recoverability codes are assigned to upport items to indicate the disposition action on unserviceable items. The recoverability code is entered in the fifth position of the Uniform SMR Code format as follows:

Recoverability codes	*Definition*
Z	Nonreparable item. When unserviceable, condemn and dispose at the level indicated in position 3.
D	Reparable item. When beyond lower level repair capability, return to depot. Condemnation and disposal not authorized below depot level.
A	Item requires special handling or condemnation procedures because of specific reasons (i.e., precious metal content, high dollar value, critical material or hazardous material). Refer

Recoverability codes *Definition*

to appropriate manuals/directives for specific instructions.

c. National Stock Number. Indicates the National stock number assigned to the item and will be used for requisitioning purposes.

d. Part Number. Indicates the primary number used by the manufacturer (individual, company, firm, corporation, or Government activity), which controls the design and characteristics of the item by means of its engineering drawings, specifications, standards, and inspection requirements to identify an item or range of items.

NOTE

When a stock numbered item is requisitioned, the repair part received may have a different part number than the part being replaced.

e. Federal Supply Code for manufacturer (FSCM). The FSCM is a 5-digit numeric code listed in SB 708-41742 which is used to identify the manufacturer, distributor, or Government agency, etc.

f. Description. Indicates the Federal item name and, if required, a minimum description to identify the item.

g. Unit of Measure (U/M). Indicates the standard of the basic quantity of the listed item as used in performing the actual maintenance function. This measure is expressd by a two-character alphabetical abbreviation (e.g., ea, in, pr, etc). When the unit of measure differs from the unit of issue, the lowest unit of issue that will satisfy the required units of measure will be requisitioned.

h. Quantity Incorporated in Unit. Indicates the quantity of the item used in the breakout shown on the illustration figure, which is prepared for a functional group, subfunctional group, or an assembly.

4. Special Information

a. The following publications pertain to the OL-192/GMD-1 and OL-192A/GMD-1 and its components:
TM 11-6660-263-10, Meteorological Data Processing Groups OL-192/GMD-1 and OL-192A/GMD-1
TM 11-6660-263-24-1, Meteorological Data Processing Groups OL-192/GMD-1 and OL-192A/GMD-1
TM 11-6660-263-24-2, Meteorological Data Processing Groups OL-192/GMD-1 and OL-192A/GMD-1; Calculator, Programmable CP-1387/U (HP 9825A Desktop Computer)
TM 11-6660-263-24-3, Meteorological Data Processing Groups OL-192/GMD-1 and OL-192A/GMD-1; Reader-Perforator RP-263/GMD-1 (REMEX Model RAB612XBA)
TM 11-6660-263-24-4, Meteorological Data Processing OL-192/GMD-1 and OL-192A/GMD-1; Cable Assembly, Special Purpose CX-13096/U (HP 98032A 16-Bit Interface)

b. The illustrations in this manual are identical to those published in TM-6660-263-34P. Only those parts assigned the third position SMR maintenance code "C" or "O" are listed in the tabular listing; thereofore, there may be a break in the item number sequence. Only illustrations containing organizational authorized items appear in this manual.

5. How to Locate Repair Parts

a. When National stock number or part number is unknown.

(1) First. Using the table of contents, determine the functional group within which the item belongs. This is necessary since illustrations are prepared for functional groups and listings are divided into the same groups.

(2) *Second.* Find the illustration covering the functional group to which the item belongs.

(3) *Third.* Identify the item on the illustration and note the illustration figure and item number of the item.

(4) *Fourth.* Using the Repair Parts Listing, find the figure and item number noted on the illustration.

b. When National stock number or part number is known.

(1) *First.* Using the Index of National Stock Numbers and Part Numbers, find the pertinent National stock number or part number. This index is in NIIN sequence followed by a list of part numbers in alphameric sequence, cross-referenced to the illustration figure number and item number.

(2) *Second.* After finding the figure and item number, locate the figure and item number in the repair parts list.

6. Abbreviations

Not applicable.

(Next printed page is 4)



Figure 1. Meteorological Data Processing Groups OL-192/GMD-1 and OL-192A/GMD-1.

(1) ILLUSTRATION (a) FIG NO.	(1) ILLUSTRATION (b) ITEM NO.	(2) SMR CODE	(3) NATIONAL STOCK NUMBER	(4) PART NUMBER	(5) FSCM	(6) DESCRIPTION USABLE ON CODE	(7) U/M	(8) QTY INC IN UNIT
						GROUP 00 METEOROLOGICAL DATA PROCESSING		
						GROUPS OL-192/GMD-1 AND		
						OL-192A/GMD-1		
1	1	XDODD		SCD937531	80063	READER/PERF ASSY.....	EA	1
1	2	XDODD		CP-1387/U	80058	CALCULATOR,PROGRA.....	EA	1



CALCULATOR

EL7BD003

Figure 2. Calculator, Programmable CP-1387/U (Sheet 1 of 2).



Figure 2. Calculator, Programmable CP-1387/U (Sheet 2 of 2).

(1) ILLUSTRATION (a) FIG NO.	(1) ILLUSTRATION (b) ITEM NO.	(2) SMR CODE	(3) NATIONAL STOCK NUMBER	(4) PART NUMBER	(5) FSCM	(6) DESCRIPTION / USABLE ON CODE	(7) U/M	(8) QTY INC IN UNIT
						GROUP 01 CALCULATOR,PROGRAMMABLE CP-1387/U		
2	2	PAOZZ	4130-01-081-3896	4208-0110	28480	FILTER MEDIA,AIR CO	EA	1
2	9	PAOZA	6660-01-082-7989	SC-C-937524-1	80063	CARTRIDGE,DATA PROG	EA	4
2	22	XDOZZ		9270-048	28480	PAPER,THERMAL PTR	EA	3
2	23	PAOZZ	6150-00-008-5075	KH7081	70903	CABLE ASSEMBLY,POWE	EA	1



Figure 3. Housing Assembly, Transformer.

(1) ILLUSTRATION (a) FIG NO.	(1) ILLUSTRATION (b) ITEM NO.	(2) SMR CODE	(3) NATIONAL STOCK NUMBER	(4) PART NUMBER	(5) FSCM	(6) DESCRIPTION USABLE ON CODE	(7) U/M	(8) QTY INC IN UNIT
						GROUP 010404 HOUSING ASSEMBLY,TRANSFORMER		
3	3	PAOZZ	5999-01-082-4375	2110-0545	28480	CAP,ELECTRICAL	EA	1
3	5	PAOZZ	5920-00-356-2199	312003	75915	FUSE,CARTRI TASK 4A	EA	1



Figure 4. Bezel Assembly, Calculator.

(1) ILLUSTRATION (a) FIG NO.	(1) ILLUSTRATION (b) ITEM NO.	(2) SMR CODE	(3) NATIONAL STOCK NUMBER	(4) PART NUMBER	(5) FSCM	(6) DESCRIPTION	(7) U/M	(8) QTY INC IN UNIT
						USABLE ON CODE		
						GROUP 0105 BEZEL ASSEMBLY,CALCULATOR		
4	23	XDOZZ		09815-20602	28480	SPINDLE,PAPER.....	EA	1



Figure 5. Perforator/Reader RP-263/GMD-1 (Sheet 1 of 2)



Figure 5. Perforator/Reader RP-263/GMD-1 (Sheet 2 of 2).

(1) ILLUSTRATION (a) FIG NO.	(1) ILLUSTRATION (b) ITEM NO.	(2) SMR CODE	(3) NATIONAL STOCK NUMBER	(4) PART NUMBER	(5) FSCM	(6) DESCRIPTION USABLE ON CODE	(7) U/M	(8) QTY INC IN UNIT
						GROUP 02 PERFORATOR/READER RP-263/GMD-1		
5	1	PDODD	6660-01-068-8642	RP-263/GMD-1	80058	READER-PERFORATOR	EA	1
5	2	XDOZZ		109817-1	16550	DECAL	EA	1
5	3	XDOZZ		113402-1	16550	DECAL,CAUTION	EA	1
5	4	XDOZZ		110388-1	16550	DECAL,PUNCH LUBE	EA	1
5	5	XDOZZ		110884-1	16550	DECAL,WRN HAZARD	EA	1
5	6	XDOZZ		111933-4	16550	DECAL,XFMR VOLTAGES	EA	1
5	8	XDOZZ		716018-113	16550	LABEL,IDENT PLATE	EA	1
5	33	XDOZZ		H565A6875B	83014	HANDLE	EA	2
5	34	PAOZZ	1560-00-932-9853	113523-1	81996	CHAD BOX	EA	1



SWITCH PLATE



SIDE VIEW

EL7BD024

Figure 6. Front Panel Assembly, Switch Plate Assembly.

(1) ILLUSTRATION (a) FIG NO.	(1) ILLUSTRATION (b) ITEM NO.	(2) SMR CODE	(3) NATIONAL STOCK NUMBER	(4) PART NUMBER	(5) FSCM	(6) DESCRIPTION USABLE ON CODE	(7) U/M	(8) QTY INC IN UNIT
						GROUP 0202 FRONT PANEL ASSEMBLY		
6	1	PAOZZ	6210-01-094-1576	B7952-04	09353	LENS	EA	1
6	3	XDOZZ		715063-330	16550	ROCKER CAP	EA	1
6	5	XDOZZ		715063-320	16550	ROCKER CAP	EA	1
6	9	PAOZZ	6210-00-557-8102	362	12073	LAMP	EA	2
6	11	XDOZZ		715063-311	16550	ROCKER CAP	EA	1



Figure 7. Power Supply Assembly.

(1) ILLUSTRATION (a) FIG NO.	(1) ILLUSTRATION (b) ITEM NO.	(2) SMR CODE	(3) NATIONAL STOCK NUMBER	(4) PART NUMBER	(5) FSCM	(6) DESCRIPTION USABLE ON CODE	(7) U/M	(8) QTY INC IN UNIT
						GROUP 0208 POWER SUPPLY ASSEMBLY		
7	2	XDOZZ		MDA2AMP	71400	FUSE	EA	1
7	4	PAOZZ	5920-00-823-0624	MDA4AMP	71400	FUSE,CARTRIDGE	EA	1



Figure 8. Power Supply Assembly, Transformer Assembly.

(1) ILLUSTRATION (a) FIG NO.	(1) ILLUSTRATION (b) ITEM NO.	(2) SMR CODE	(3) NATIONAL STOCK NUMBER	(4) PART NUMBER	(5) FSCM	(6) DESCRIPTION USABLE ON CODE	(7) U/M	(8) QTY INC IN UNIT
8	7	XDOZZ		705725-130	16550	FUSE.....	EA	1



Figure 9. Printed Circuit Card Assembly, Power Supply (Sheet 1 of 2).

REF. DES.	ITEM NO.	REF. DES.	ITEM NO.	REF. DES.	ITEM NO.	REF. DES.	ITEM NO.
C1	1	CR11	8	J106	17	R14	32
C2	1	CR12	6	J107	18	R15	33
C3	2	CR13	6	J108	19	R16	34
C4	3	CR14	6	J109	20	R17	35
C5	4	CR15	6	Q1	21	R18	35
C8	5	CR16	9	Q2	22	R20	36
C9	3	CR17	9	R1	23	TP1	37
C10	3	CR18	9	R2	24	TP2	38
CR1	6	CR19	6	R3	25	TP3	38
CR2	6	CR21	10	R4	23	TP4	38
CR3	7	GR22	9	R5	26	TP5	38
CR4	7	F1	11	R6	27	TP6	38
CR5	7	F2	12	R7	26	TP7	38
CR6	7	F3	13	R8	28	TP8	38
CR7	7	F4	12	R9	28	Z1	39
CR8	7	J103	14	R10	29	Z2	39
CR9	7	J104	15	R11	30		
CR10	7	J105	16	R13	31		

EL7BD056

Figure 9. Printed Circuit Card Assembly, Power Supply (Sheet 2 of 2).

(1) ILLUSTRATION (a) FIG NO.	(1) ILLUSTRATION (b) ITEM NO.	(2) SMR CODE	(3) NATIONAL STOCK NUMBER	(4) PART NUMBER	(5) FSCM	(6) DESCRIPTION / USABLE ON CODE	(7) U/M	(8) QTY INC IN UNIT
						GROUP 020801 PRINTED CIRCUIT CARD ASSEMBLY, POWER SUPPLY		
9	11	PAOZZ	5920-00-480-4088	GMW1-4	71400	FUSE,CARTRIDGE.....	EA	1
9	12	PAOZZ	5920-01-063-7799	GMW4AMP	71400	FUSE,SPECIAL.....	EA	2
9	13	XDOZZ		GMW2AMP	71400	FUSE.....	EA	1

STOCK NUMBER	FIGURE NO.	ITEM NO.	STOCK NUMBER	FIGURE NO.	ITEM NO.
6150-00-008-5075	2	23	5920-01-063-7799	9	12
5920-00-356-2199	3	5	6660-01-068-8642	5	1
5920-00-480-4088	9	11	4130-01-081-3896	2	2
6210-00-557-8102	6	9	5999-01-082-4375	3	3
5920-00-823-0624	9	4	6660-01-082-7989	2	9
1560-00-932-9853	5	34	6210-01-094-1576	6	1

PART NUMBER	FSCM	FIG. NO.	ITEM NO.	PART NUMBER	FSCM	FIG. NO.	ITEM NO.
B7952-04	09353	6	1	110884-1	16550	5	5
CP-1387/U	80058	1	2	111933-4	16550	5	6
GMW1-4	71400	9	11	113402-1	16550	5	3
GMW2AMP	71400	9	13	113523-1	81996	5	34
GMW4AMP	71400	9	12	2110-0545	28480	3	3
H565A6875B	83014	5	33	312003	75915	3	5
KH7081	70903	2	23	362	12073	6	9
MDA2AMP	71400	7	2	4208-0110	28480	2	2
MDA4AMP	71400	7	4	705725-130	16550	8	7
RP-263/GMD-1	80058	5	1	715063-311	16550	6	11
SC-C-937524-1	80063	2	9	715063-320	16550	6	5
SCD937531	80063	1	1	715063-330	16550	6	3
09815-20602	28480	4	23	716018-113	16550	5	8
109817-1	16550	5	2	9270-048	28480	2	22
110388-1	16550	5	4				

☆U.S. GOVERNMENT PRINTING OFFICE:1981-703-029/1150

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

THEN JOT DOWN THE DOPE ABOUT IT ON THIS FORM, CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL.

SOMETHING WRONG WITH THIS PUBLICATION?

FROM (PRINT YOUR UNIT'S COMPLETE ADDRESS)
Commander
Stateside Army Depot
ATTN: AMSTA-US
Stateside, N.J. 07703

DATE SENT
10 July 1975

PUBLICATION NUMBER	PUBLICATION DATE	PUBLICATION TITLE
TM 11-5840-340-20P	23 Jan 78	Radar Set AN/PRC-76

BE EXACT PIN-POINT WHERE IT IS

PAGE NO	PARA GRAPH	FIGURE NO	TABLE NO
33			
44		19	
45			

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

For item 2, change the NSN to read: 5835-00-134-9186.
Reason: Accuracy.

Identify the cover on the junction box (item no. 5).
Reason: It is a separate item and is not called out on figure 19.

Add the cover of the junction box as an item in the listing for figure 19.
Reason: Same as above

SAMPLE

PRINTED NAME GRADE OR TITLE AND TELEPHONE NUMBER
SSG . . M. DeSpirit of 999-1776

SIGN HERE

DA FORM 1 JUL 79 2028-2

PREVIOUS EDITIONS ARE OBSOLETE.

P.S.--IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS

TEAR ALONG PERFORATED LINE

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

SOMETHING WRONG WITH THIS PUBLICATION?

FROM (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER	PUBLICATION DATE	PUBLICATION TITLE
TM 11-6660-263-20P	14 May 81	Meteorological Data Processing Groups OL-192/GMD-1 and OL-192A/GMD-1

BE EXACT PIN-POINT WHERE IT IS

PAGE NO	PARAGRAPH	FIGURE NO	TABLE NO

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE

DA FORM 1 JUL 79 2028-2

PREVIOUS EDITIONS ARE OBSOLETE

P.S.—IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS

TEAR ALONG PERFORATED LINE

REVERSE OF DA FORM 2028-2

FILL IN YOUR UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

POSTAGE AND FEES PAID
DEPARTMENT OF THE ARMY
DOD 314

U.S. MAIL

OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE $300

TEAR ALONG PERFORATED LINE

Commander
US Army Communications and
Electronics Materiel Readiness Command
ATTN: DRSEL-ME-MQ
Fort Monmouth, New Jersey 07703

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

SOMETHING WRONG WITH THIS PUBLICATION?

FROM (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER	PUBLICATION DATE	PUBLICATION TITLE
TM 11-6660-263-20P	14 May 81	Meteorological Data Processing Groups OL-192/GMD-1 and OL-192A/GMD-1

BE EXACT PIN-POINT WHERE IT IS

PAGE NO	PARA GRAPH	FIGURE NO	TABLE NO

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE

DA FORM 1 JUL 79 2028-2

PREVIOUS EDITIONS ARE OBSOLETE

P.S. IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS

REVERSE OF DA FORM 2028-2

TEAR ALONG PERFORATED LINE

FILL IN YOUR UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE $300

POSTAGE AND FEES PAID
DEPARTMENT OF THE ARMY
DOD 314

U.S. MAIL

Commander
US Army Communications and
Electronics Materiel Readiness Command
ATTN: DRSEL-ME-MQ
Fort Monmouth, New Jersey 07703

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL PUBLICATIONS

THEN . . JOT DOWN THE DOPE ABOUT IT ON THIS FORM, CAREFULLY TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL.

SOMETHING WRONG WITH THIS PUBLICATION?

FROM (PRINT YOUR UNIT'S COMPLETE ADDRESS)

DATE SENT

PUBLICATION NUMBER	PUBLICATION DATE	PUBLICATION TITLE
TM 11-6660-263-20P	14 May 81	Meteorological Data Processing Groups OL-192/GMD-1 and OL-192A/GMD-1

BE EXACT PIN-POINT WHERE IT IS

PAGE NO	PARA-GRAPH	FIGURE NO	TABLE NO

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT:

PRINTED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE

DA FORM 1 JUL 79 2028-2

PREVIOUS EDITIONS ARE OBSOLETE

P.S. IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR RECOMMENDATION MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS

TEAR ALONG PERFORATED LINE

REVERSE OF DA FORM 2028-2

TEAR ALONG PERFORATED LINE

FILL IN YOUR UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

POSTAGE AND FEES PAID
DEPARTMENT OF THE ARMY
DOD 314

U.S. MAIL

OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE $300

Commander
US Army Communications and
Electronics Materiel Readiness Command
ATTN: DRSEL-ME-MQ
Fort Monmouth, New Jersey 07703

By Order of the Secretary of the Army:

E. C. MEYER
General, United States Army
Chief of Staff

Official:

J. C. PENNINGTON
Major General, United States Army
The Adjutant General

DISTRIBUTION:

To be distributed in accordance with DA Form 12-25C Organizational maintenance requirements for Meteorlgy.

DEPARTMENT OF THE ARMY
US ARMY AG PUBLICATIONS CENTER
1655 WOODSON ROAD
ST. LOUIS, MISSOURI 63114

OFFICIAL BUSINESS
PENALTY FOR PRIVATE USE $300

POSTAGE AND FEES PAID
DEPARTMENT OF THE ARMY
DOD 314

U.S.MAIL